### LIMITED WARRANTY

The Manufacturer warrants to the original consumer purchaser that this product as manufactured is free from defects in materials and workmanship. For a period of one (1) year from date of purchase by the original consumer purchaser, we will repair or replace, at our option, without charge for parts or labor incurred in replacing parts, any part which we find to be defective due to materials or workmanship. This Warranty is subject to the following limitations and exclusions.

- 1. This warranty does not apply to the engine, transaxle/transmission components, battery (except as noted below) or components parts thereof. Please refer to the applicable manufacturer's warranty on these items.
- 2. Transportation charges for the movement of any power equipment unit or attachment are the responsibility of the purchaser. Transportation charges for any parts submitted for replacement under this warranty must be paid by the purchaser unless such return is requested by the manufacturer.
- 3. Battery Warranty: On products equipped with a Battery, we will replace, without charge to you, any battery which we find to be defective in manufacture, during the first ninety (90) days of ownership. After ninety (90) days, we will exchange the Battery, charging you 1/12 of the price of a new Battery for each full month from the date of the original sale. Battery must be maintained in accordance with the instructions furnished.
- 4. The Warranty period for any products used for rental or commercial purposes is limited to 45 days from the date of original purchase.
- 5. This Warranty applies only to products which have been properly assembled, adjusted, operated, and maintained in accordance with the instructions furnished. This Warranty does not apply to any product which has been subjected to alteration, misuse, abuse, improper assembly or installation, delivery damage, or to normal wear of the product.
- 6. Exclusions: Excluded from this Warranty are belts, blades, blade adapters, normal wear, normal adjustments, standard hardware and normal maintenance.
- 7. In the event you have a claim under this Warranty, you must return the product to an authorized service dealer.


Should you have any unanswered questions concerning this Warranty, contact:

Weed Eater Customer Service Department 9335 Harris Corners Parkway Charlotte, NC 28269 USA In Canada contact: Weed Eater Customer Service Department 5855 Terry Fox Way Mississauga, Ontario L5V 3E4

giving the model number, serial number and date of purchase of your product and the name and address of the authorized dealer from whom it was purchased. THIS WARRANTY DOES NOT APPLY TO INCIDENTAL OR CONSEQUENTIAL DAMAGES AND ANY IMPLIED WARRANTIES ARE LIMITED TO THE SAME TIME PERIODS STATED HEREIN FOR OUR EXPRESSED WARRANTIES. Some areas do not allow the limitation of consequential damages or limitations of how long an implied Warranty may last, so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights, and you may have other rights which vary from locale to locale.

This is a limited Warranty within the meaning of that term as defined in the Magnuson-Moss Act of 1975.

## WEED EATER®



## REPAIR PARTS MANUAL MODEL NO. 96112011501 Rotary Lawn Mower


For Parts and Service or Technical Assistance, call 1-800-487-5951

### WEED EATER®

**NOTE:** Gasoline containing up to 10% ethanol (E10) is acceptable for use in this machine. The use of any gasoline exceeding 10% ethanol (E10) will void the product warranty.

580 70 72-27 Rev. 1 05.10.12 BY

# WEED EATER ROTARY LAWN MOWER - - MODEL NUMBER 96112011501



# WEED EATER ROTARY LAWN MOWER - - MODEL NUMBER 96112011501

KEY         PART         DESCRIPTION         NO.         NO.         NO.           NO.         NO.         NO.         NO.         NO.         NO.           NO.         NO.         NO.         NO.         NO.         NO.           1         532 19 60-25         Control Bar         22         532 15 02-15         22.15         532 18 92-37         23         532 18 92-37         23         532 18 92-37         26         532 17 09-77         26         532 17 09-77         26         532 17 09-77         28         532 17 09-77         28         532 17 09-77         28         532 17 09-77         28         532 18 0-74         20         532 18 0-74         20         532 18 0-74         20         532 18 0-74         20         532 18 0-74         20         532 18 0-74         20         532 18 0-74         20         532 18 0-74         20         532 18 0-74         20         532 18 0-74         20         532 18 0-74         20         532 18 0-74         20         532 18 0-70         20         532 18 0-70         20         532 18 0-70         20         532 18 0-70         20         532 18 0-70         20         532 18 0-70         20         532 18 0-70         20         532 18 0-70         20 <t< th=""><th>DESCRIPTION</th><th>Rod, Hinge</th><th>Rear Skirt</th><th>Blade Adapter</th><th>Handle Bracket Assembly, RH</th><th>Handle Bracket Assembly, LH</th><th>Washer</th><th>Spacer</th><th>Engine, Briggs &amp; Stratton, Model No. 9L602-</th><th>1611-F1 (For engine service and replacement</th><th>parts, call Briggs &amp; Stratton at 1-800-233-3723)</th><th>Bolt, Shoulder 3/8-16 x 2-1/2</th><th>Wheel &amp; Tire Assembly</th><th>Screw, Hex Head, Threaded, Rolled 3/8-16 x 1</th><th>Housing Kit</th><th>Screw, Hex Head, Machine, Grade 8, 3/8-24 x 1-3/8</th><th>Screw</th><th>Danger Decal</th><th>Nut, Hex, Nylock 3/8-16</th><th>Locknut, Hex 1/4-20</th><th>Decal, Warning</th><th>Operator's Manual, English</th><th>Operator's Manual, Spanish</th><th>Replacement Parts Manual</th></t<>	DESCRIPTION	Rod, Hinge	Rear Skirt	Blade Adapter	Handle Bracket Assembly, RH	Handle Bracket Assembly, LH	Washer	Spacer	Engine, Briggs & Stratton, Model No. 9L602-	1611-F1 (For engine service and replacement	parts, call Briggs & Stratton at 1-800-233-3723)	Bolt, Shoulder 3/8-16 x 2-1/2	Wheel & Tire Assembly	Screw, Hex Head, Threaded, Rolled 3/8-16 x 1	Housing Kit	Screw, Hex Head, Machine, Grade 8, 3/8-24 x 1-3/8	Screw	Danger Decal	Nut, Hex, Nylock 3/8-16	Locknut, Hex 1/4-20	Decal, Warning	Operator's Manual, English	Operator's Manual, Spanish	Replacement Parts Manual
PART         DESCRIPTION           532 19 60-25         Control Bar           532 19 47-88         Rope Guide           532 12 50-78         Engine Washer           532 15 50-44         Lower Handle           532 13 2-0-04         Uut, Hex 1/4-20           532 13 12-0-4         Lower Handle           532 19 15-74         Bolt, Carriage           532 19 15-74         Bolt, Carriage           532 19 16-27-8         Screw, Hex Washer Head, Self-Tapping           #10-24 x 1/2         Screw, Hex Washer Head           #32 16 27-78         Cable, Engine Zone Control           532 17 88-48         Screw, Hex Washer Head           #10-16 x 5/8         Screw, Handle           532 17 88-48         Wire Tie           532 17 88-48         Hairpin, Cotter           532 17 88-4         Hairpin, Cotter           532 24 50-19         Knob, Handle           532 44 50-19         Knob, Handle           532 85 02-63         Helical Lock Washer           532 18 50-63         Helical Lock Washer		532 15 02-15	532 18 92-39	532 85 09-77	532 17 09-75	532 17 09-77	532 06 15-37	532 13 66-24	:			532 06 76-09	532 43 61-20	532 15 04-06	532 43 77-00	532 85 10-84	532 14 97-41	532 40 47-63	873 22 06-00	873 80 04-00	532 40 47-64	532 19 37-47	532 19 37-50	580 70 72-27
PART NO. 532 19 60-25 532 19 60-25 532 19 47-88 532 19 60-26 532 15 50-44 532 19 15-74 532 19 15-74 532 19 15-74 532 18 92-41 532 16 27-78 532 16 27-78 532 16 27-78 532 16 27-78 532 17 88-48 532 17 88-48 532 17 88-48 532 18 50-19 532 85 02-63 532 85 02-63 532 85 10-74 532 85 10-74	Α NO NO	22	23	25	56	27	28	59	30			35	36	38	39	40	4	42	43	26	;	1	;	;
	DESCRIPTION	Control Bar	Rope Guide	Engine Washer	Upper Handle	Lower Handle	Nut, Hex 1/4-20	Bolt, Carriage	Up-Stop Bracket	Screw, Hex Washer Head, Self-Tapping	#10-24 x 1/2	Cable, Engine Zone Control	Screw, Hex Washer Head	#10-16×5/8	Wire Tie	Hairpin, Cotter	Knob, Handle	Discharge Guard	Helical Lock Washer	Spring, Hinge	Washer, Hardened	Blade, 20"	Bracket, Hinge	
NO. 1	PART NO.	532 19 60-25				532 15 50-44	532 13 20-04	532 19 15-74	532 43 00-34	532 18 92-41		532 16 27-78	532 17 88-48		532 06 64-26	532 05 17-93	532 44 50-19	532 43 20-40	532 85 02-63	532 41 18-32	532 85 10-74	532 14 51-06	532 08 86-02	
	KEY NO.	-	2	က	4	2	9	7	80	6			Ξ		12	13	14	15	16	18	19	50	2	

3